

NIMA DOLLY INSTRUCTIONS

OPERATIONAL INSTRUCTIONS:

- 1. Orient casters in the direction of travel.
- 2. Dolly to be pushed or pulled from the long axes, as shown in detail below, shoulder height, not to exceed 52" above floor.



MAXIMUM LOADING: 20 (UPHOLSTERED)

MAXIMUM LOADING: 16 (UPHOLSTERED)